

# FOCUSED ON PRODUCTIVITY, QUALITY AND COST-EFFICIENCY

Meeting the challenge of compressed air contamination.



ENGINEERING YOUR SUCCESS.





## FOCUSED ON COMPRESSED AIR CONTAMINATION


Compressed air is often a vital element in modern production processes. Irrespective of whether it comes into direct contact with the product or is used to automate a process, provide motive power, packaging, or even to generate other gases on-site, a clean, dry, reliable compressed air supply is essential.

In order to achieve a safe and efficient system, it is important to understand the sources of compressed air contamination and the types of contaminants which must be reduced or eliminated. Once these issues have been identified, we can implement measures to protect the consumer and ensure a smooth-running and cost-effective production facility.

“A clean and reliable compressed air supply is a crucial part of the production process”

---

Operations Manager, Pharmaceutical Company



With up to 100 million micro-organisms in every cubic metre of ambient air, just a few of these entering a clean environment can have a costly impact

---


## FOCUSED ON IDENTIFYING THE RISKS

In a typical compressed air system, there are ten major contaminants:

**Water Vapour, Water Aerosols and Condensed Water**

Oil is often perceived to be the cause of liquid contamination, but in the majority of instances, it is actually oily condensate that is being observed. In fact, in a typical compressed air system, up to 99.9% of the total liquid contamination is water.

The ability of air to hold water vapour is dependent upon its pressure and temperature. The higher the temperature, the more water vapour that can be held by the air. The higher the pressure, a greater amount of water vapour is squeezed out. As large volumes of air are drawn into the compressor and compressed, the temperature of the air increases significantly. This allows the heated air



to easily retain the water vapour in the atmospheric air. Prior to exiting the compressor, compressed air is normally cooled to a usable temperature. This reduces the air's ability to retain water vapour, resulting in a proportion of the water vapour condensing into liquid water.

This condensed water, together with water aerosols, leads to corrosion in the storage and distribution system, damage to production equipment, and can also spoil the end product.

#### Oil Vapour

Atmospheric air also contains oil in the form of unburned hydrocarbons which are drawn into the compressor intake. Typical concentrations can vary between 0.05 and 0.5mg per cubic metre of ambient air. Once inside the compressed air system, oil vapour will cool and condense, causing the same contamination issues as liquid oil. Vaporised oil from the compression stage of a lubricated compressor will also condense within the system and add to the overall level of oil contamination.

#### Liquid Oil and Oil Aerosols

Most air compressors use oil in the compression stage for sealing, lubrication and cooling. During operation, lubricating

oil is carried over into the compressed air system as liquid oil and aerosols.

This oil mixes with water in the air and is often very acidic, causing damage to the compressed air storage and distribution system, production equipment and final product.

#### Atmospheric Dirt

In an industrial environment, every cubic metre of atmospheric air typically contains 140 million dirt particles. 80% of these particles are less than 2 microns in size and are too small to be captured by an intake filter, and therefore they pass directly into the compressor itself.

#### Micro-organisms

Bacteria and viruses will also be drawn into the compressed air system through the compressor intake and warm, moist air provides an ideal environment for the growth of micro-organisms. Every cubic metre of ambient air can contain up to 100 million micro-organisms. And even if only a few of these enter a clean, sterile environment or production process, it can have a costly impact on product quality, and may even render a product entirely unfit for use and subject to recall.

#### Rust and Pipescale

Rust and pipescale can be found in air receivers and the piping of "wet systems" (systems without adequate purification equipment) or systems which were operated "wet" prior to purification equipment being installed. Over time, this contamination breaks away to cause damage or blockage in production equipment, which in turn can lead to problems in the final product and processes.



## FOCUSED ON CONTAMINATION: THE RISK POINTS IN THE SYSTEM


The ten main contaminants in a compressed air system come from four main sources:

**Source 1** – Ambient Air

**Source 2** – The Air Compressor

**Source 3** – The Air Receiver

**Source 4** – The Distribution Piping



### Atmospheric contamination entering the compressor

- Water Vapour
- Micro-organisms
- Atmospheric Dirt
- Oil Vapour

### Contamination introduced by the compressor


- Water Aerosols
- Condensed Liquid Water
- Liquid Oil
- Oil Aerosols (from the compressor lubricant)

**No.1**

Ambient Air

**No.2**

The Air Compressor



**Contamination introduced by the air receiver and distribution piping**

- Rust
- Pipescale

**Total contamination entering the compressed air distribution system**

- Water Vapour
- Micro-organisms
- Atmospheric Dirt
- Oil Vapour
- Water Aerosols
- Condensed Liquid Water
- Liquid Oil
- Oil Aerosols
- Rust
- Pipescale

**No.3**  
The Air Receiver

**No.4**  
The Distribution Piping

Contaminant Source



# FOCUSED ON PREVENTION AND REDUCTION

Failure to prevent or reduce contamination can cause numerous problems in the compressed air system, such as:

- Microbiological contamination
- Corrosion within storage vessels and the distribution system
- Damaged production equipment
- Blocked or frozen valves, cylinders, air motors and tools
- Premature unplanned desiccant changes for adsorption dryers

In addition to problems associated with the compressed air system itself, allowing contamination such as water, solid particulate, oil and micro-organisms to exhaust from valves, cylinders, air motors and tools, can lead to an unhealthy working environment. This will increase the potential for personal injury, staff absences and financial compensation claims.

Compressed air contamination will ultimately lead to:

- Inefficient production processes
- Spoiled, damaged or reworked products
- Reduced production efficiency
- Increased manufacturing costs





“Parker's knowledge and technical expertise is incomparable”

Operations Director, UK

## FOCUSED ON COMPLYING WITH INTERNATIONAL STANDARDS

ISO8573-1 lists the main contaminants as solid particulate, water and oil. The purity levels for each contaminant are shown separately in tabular form, however for ease of use, this document combines all three contaminants into one easy to use table.

ISO8573-1:2010 CLASS	Solid Particulate			Mass Concentration mg/m <sup>3</sup>	Water		Oil
	Maximum number of particulates per m <sup>3</sup>				Vapour Pressure Dewpoint	Liquid g/m <sup>3</sup>	Total Oil (aerosol liquid and vapour)
	0.1 - 0.5 micron	0.5 - 1 micron	1 - 5 micron				
0	As specified by the equipment user or supplier and more stringent than Class 1						
1	≤ 20,000	≤ 400	≤ 10		≤ -70°C		0.01
2	≤ 400,000	≤ 6,000	≤ 100		≤ -40°C		0.1
3		≤ 90,000	≤ 1,000		≤ -20°C		1
4			≤ 10,000		≤ +3°C		5
5			≤ 100,000		≤ +7°C		
6				≤ 5	≤ +10°C		
7				5 - 10		≤ 0.5	
8						0.5 - 5	
9						5 - 10	
X				> 10		> 10	> 10

# FOCUSED ON WORKING TOGETHER

At Parker, we have a complete range of products that can protect your compressed air system at every dewpoint, every flow and every pressure, across every industry. And because all of our solutions are part of the Parker family, everything is designed to integrate perfectly, and work smoothly and efficiently for you.

- World leaders in compressed air and gas treatment
- Three specialist brands, concentrated on technological expertise and innovation
- Focused on meeting customer needs – energy efficient, lowest cost of ownership, productivity and profitability, service and support



To find out more about Parker compressed air and gas treatments, visit [solutions.parker.com/focusedonCAGT](https://solutions.parker.com/focusedonCAGT)

---



**Parker** | domnick  
hunter

**FOCUSED ON  
FILTRATION AND  
SEPARATION**

**Parker** | Hiross

**FOCUSED ON  
REFRIGERATION  
AND COOLING**

**Parker** | Zander

**FOCUSED ON  
ADSORPTION**

# Parker Worldwide

## Europe, Middle East, Africa

### AE – United Arab Emirates, Dubai

Tel: +971 4 8127100  
parker.me@parker.com

### AT – Austria, Wiener Neustadt

Tel: +43 (0)2622 23501-0  
parker.austria@parker.com

### AT – Eastern Europe, Wiener Neustadt

Tel: +43 (0)2622 23501 900  
parker.easteurope@parker.com

### AZ – Azerbaijan, Baku

Tel: +994 50 2233 458  
parker.azerbaijan@parker.com

### BE/LU – Belgium, Nivelles

Tel: +32 (0)67 280 900  
parker.belgium@parker.com

### BG – Bulgaria, Sofia

Tel: +359 2 980 1344  
parker.bulgaria@parker.com

### BY – Belarus, Minsk

Tel: +48 (0)22 573 24 00  
parker.poland@parker.com

### CH – Switzerland, Etoy

Tel: +41 (0)21 821 87 00  
parker.switzerland@parker.com

### CZ – Czech Republic, Klecany

Tel: +420 284 083 111  
parker.czechrepublic@parker.com

### DE – Germany, Kaarst

Tel: +49 (0)2131 4016 0  
parker.germany@parker.com

### DK – Denmark, Ballerup

Tel: +45 43 56 04 00  
parker.denmark@parker.com

### ES – Spain, Madrid

Tel: +34 902 330 001  
parker.spain@parker.com

### FI – Finland, Vantaa

Tel: +358 (0)20 753 2500  
parker.finland@parker.com

### FR – France, Contamine s/Arve

Tel: +33 (0)4 50 25 80 25  
parker.france@parker.com

### GR – Greece, Piraeus

Tel: +30 210 933 6450  
parker.greece@parker.com

### HU – Hungary, Budaörs

Tel: +36 23 885 470  
parker.hungary@parker.com

### IE – Ireland, Dublin

Tel: +353 (0)1 466 6370  
parker.ireland@parker.com

### IL – Israel

Tel: +39 02 45 19 21  
parker.israel@parker.com

### IT – Italy, Corsico (MI)

Tel: +39 02 45 19 21  
parker.italy@parker.com

### KZ – Kazakhstan, Almaty

Tel: +7 7273 561 000  
parker.easteurope@parker.com

### NL – The Netherlands, Oldenzaal

Tel: +31 (0)541 585 000  
parker.nl@parker.com

### NO – Norway, Asker

Tel: +47 66 75 34 00  
parker.norway@parker.com

### PL – Poland, Warsaw

Tel: +48 (0)22 573 24 00  
parker.poland@parker.com

### PT – Portugal

Tel: +351 22 999 7360  
parker.portugal@parker.com

### RO – Romania, Bucharest

Tel: +40 21 252 1382  
parker.romania@parker.com

### RU – Russia, Moscow

Tel: +7 495 645-2156  
parker.russia@parker.com

### SE – Sweden, Spånga

Tel: +46 (0)8 59 79 50 00  
parker.sweden@parker.com

### SK – Slovakia, Banská Bystrica

Tel: +421 484 162 252  
parker.slovakia@parker.com

### SL – Slovenia, Novo Mesto

Tel: +386 7 337 6650  
parker.slovenia@parker.com

### TR – Turkey, Istanbul

Tel: +90 216 4997081  
parker.turkey@parker.com

### UA – Ukraine, Kiev

Tel: +48 (0)22 573 24 00  
parker.poland@parker.com

### UK – United Kingdom, Warwick

Tel: +44 (0)1926 317 878  
parker.uk@parker.com

### ZA – South Africa, Kempton Park

Tel: +27 (0)11 961 0700  
parker.southafrica@parker.com

## North America

### CA – Canada, Milton, Ontario

Tel: +1 905 693 3000

### US – USA, Cleveland

Tel: +1 216 896 3000

## Asia Pacific

### AU – Australia, Castle Hill

Tel: +61 (0)2-9634 7777

### CN – China, Shanghai

Tel: +86 21 2899 5000

### HK – Hong Kong

Tel: +852 2428 8008

### IN – India, Mumbai

Tel: +91 22 6513 7081-85

### JP – Japan, Tokyo

Tel: +81 (0)3 6408 3901

### KR – South Korea, Seoul

Tel: +82 2 559 0400

### MY – Malaysia, Shah Alam

Tel: +60 3 7849 0800

### NZ – New Zealand, Mt Wellington

Tel: +64 9 574 1744

### SG – Singapore

Tel: +65 6887 6300

### TH – Thailand, Bangkok

Tel: +662 186 7000

### TW – Taiwan, Taipei

Tel: +886 2 2298 8987

## South America

### AR – Argentina, Buenos Aires

Tel: +54 3327 44 4129

### BR – Brazil, Sao Jose dos Campos

Tel: +55 800 727 5374

### CL – Chile, Santiago

Tel: +56 2 623 1216

### MX – Mexico, Toluca

Tel: +52 72 2275 4200

### EMEA Product Information Centre

Free phone: 00 800 27 27 5374

(from AT, BE, CH, CZ, DE, DK, EE, ES, FI, FR, IE, IL, IS, IT, LU, MT, NL, NO, PL, PT, RU, SE, SK, UK, ZA)

### US Product Information Centre

Toll-free number: 1-800-27 27 537

[www.parker.com/gsf](http://www.parker.com/gsf)

Your local authorized Parker distributor

